

US Operating / Care instructions Verti 830/831

1. Operating instructions

Verti is an electrical system that raises and lowers cupboard shelves quickly and silently to or from the work surface.

1. Press and hold the button to start the operation.
2. Release the button when the shelves are at the desired level.

Pos. 1

The lift is equipped with safety trip panels which guarantee safe operation with no risk of being crushed.

Pos 2.

Variants of buttons for up / down operation.



2. Maintenance

The Verti is maintenance-free. Greasing and other actions are made during the manufacturing for the lifetime of the Verti. From safety point of view however some components shall be inspected each year.

- Inspections, service and repair work shall be made by competent persons.
- Remove the objects from the cabinet before maintenance and repair works are made.

3. Functional test

- Run the Verti down and up all the way to respectively end position. Check that it moves freely, without hindrance and jarring sounds. Check that no cables are jammed.
- Lower the shelves shortly. Press the trip plate under the shelves and check that the shelves are moving upwards until the plate is not pressed any longer. If there is a malfunction, contact the installer.
- Check that the upper trip plate (plastic cover) works. Press it with your fingers. The lift unit shall then move downwards.

4. Cleaning

Clean with lukewarm water and a non-scratching detergent containing soap or similar. Use a soft cloth or similar. After cleaning the surfaces shall be dried to avoid lime deposits.

**Scratching detergents or tools e.g. steel wool may not be used.
Consider that the product contains electrical components.**

5. Service & maintenance records

Order	Serial	Date
Date	Date	
Sign	Sign	
Remarks	Remarks	
Date	Date	
Sign	Sign	
Remarks	Remarks	