

US Troubleshooting Guide Baselift US English

Products

BASELIFT 6300 / 6310
 BASELIFT CORNER 6301 / 6311
 BASELIFT CORNER 6302 / 6312
 BASELIFT CORNER 6303 / 6313
 Sink Module Granberg ES11
 Sink Module Granberg ES20
 Sink Module Granberg ES30
 Sink module Granberg ESG
 Sink module Granberg ESH
 Mini kitchen module Granberg ESF
 Mini kitchen module Granberg ESF5
 Mini kitchen module Granberg ES11S2
 Combi Kitchen module Granberg ES11S4
 Combi Kitchen module Granberg ES20S4
 Combi Kitchen module Granberg ES30S4
 Combi Kitchen module Granberg ESHS4
 Cooktop module Granberg S4
 Workbench module Granberg CT

The Worktop lift unit is designed and tested to achieve optimum operation reliability and long life, provided that the operation, maintenance and inspections are carried out in accordance with the prescribed instructions. If in spite of this a fault appears you can get guidance about what to do according to the fault finding list below.

Remove the load from the worktop before fault finding and repair work is carried out. Fault finding, service and repair work shall be made by competent persons only.

If any problem remains after you have taken actions in accordance with the list below you must contact a competent technician or your supplier.

CAUTION!

Some models have two power supply cords. Unplug all power supply cords before moving or servicing this furniture.

Symptom	Action
The worktop lift unit does not move when pushing the button	<p>Check that the mains plug is connected.</p> <p>Check that the wires are properly fastened in the control device.</p> <p>Try to reset the system by pushing the button for down in 5 sec. The reset has succeeded when you hear a "click" sound. Try to run the worktop lift unit down and up all the way to respectively end position.</p>
The worktop lift unit does not move when pushing the button and it clicks three times from the control box	<p>The worktop lift is not possible to run if the connection to the security strip is broken.</p> <p>Check that the security strip is connected and that there are no damages.</p> <p>Check the connections between the security strips if the worktop lift has several security strips.</p>
The lift is not in line, the motors are in different positions	<p>Run the worktop lift down until it stops. Press down again and wait until the motor legs are in line. Now you have synchronized the motor legs.</p>